


Tabulka trvalých kotev úsek km 0,771 40 - km 0,867 31

Označení kotvy	délka kotvy (m)	délka kořene (m)	úhel (°)	počet pramenců	napínací síla (kN)
K1.1	5,5	2	25	2	100
K2.1	5,5	2	25	2	100
K3.1	5,5	2	25	2	100
K4.1	5,5	2	25	2	100
K5.1	5,5	2	25	2	100
K6.1	5,5	2	20	2	100
K7.1	7	3	20	2	100
K8.1	7	3	20	2	100
K9.1	7	3	20	2	100
K10.1	7	3	15	2	100
K11.1	7	3	15	2	100
K12.1	7	3	15	2	100
K13.1	7	3	11	2	100
K13.2	6	2	15	2	100
K14.1	7	3	11	2	100
K14.2	6	2	15	2	100
K15.1	8	3	11	2	100
K15.2	8	3	11	2	100
K16.1	8	3	11	2	100
K16.2	8	3	11	2	100
K17.1	8	3	11	2	100
K17.2	8	3	11	2	100
K18.1	8	3	11	2	100
K18.2	8	3	11	2	100
K19.1	8	3	11	2	100
K19.2	8	3	11	2	100
K20.1	8	3	11	2	100
K20.2	8	3	11	2	100
K21.1	8	3	11	2	100
K21.2	8	3	11	2	180
K22.1	8	3	11	2	100
K22.2	8	3	11	2	180
K23.1	8	3	11	2	100
K23.2	8	3	11	2	180
K24.1	8	3	11	2	100
K24.2	9	3	11	2	180
K25.1	8	3	11	2	100
K25.2	9	3	11	2	180

Způsob číslování kotev

K1.1


Tabulka trvalých kotev úsek km 0,881 61 - km 1,005 14

Označení kotvy	délka kotvy (m)	délka kořene (m)	úhel (°)	počet pramenců	napínací síla (kN)
K26.1	10	3	12	2	100
K26.2	10	3	12	2	100
K26.3	13	3	12	2	180
K27.1	10	3	12	2	100
K27.2	10	3	12	2	100
K27.3	13	3	12	2	180
K28.1	10	3	12	2	100
K28.2	10	3	12	2	100
K28.3	13	3	12	2	180
K29.1	10	3	12	2	100
K29.2	10	3	12	2	100
K29.3	13	3	12	2	180
K29.4	13	3	12	2	180
K30.1	10	3	12	2	100
K30.2	10	3	12	2	100
K30.3	13	3	12	2	180
K30.4	13	3	12	2	180
K31.1	10	3	12	2	100
K31.2	10	3	12	2	100
K31.3	13	3	12	2	180
K31.4	13	3	12	2	180
K32.1	10	3	12	2	100
K32.2	10	3	12	2	100
K32.3	13	3	12	2	180
K32.4	13	3	12	2	180
K33.1	10	3	12	2	100
K33.2	10	3	12	2	100
K33.3	13	3	12	2	180
K33.4	13	3	12	2	180
K34.1	10	3	12	2	100
K34.2	10	3	12	2	100
K34.3	13	3	12	2	180
K34.4	13	3	12	2	180
K35.1	10	3	12	2	100
K35.2	10	3	12	2	100
K35.3	13	3	12	2	180
K35.4	13	3	12	2	180
K36.1	10	3	12	2	100
K36.2	10	3	12	2	100
K36.3	13	3	12	2	180
K36.4	13	3	12	2	180
K37.1	10	3	12	2	100
K37.2	10	3	12	2	100
K37.3	13	3	12	2	180
K37.4	13	3	12	2	180

Tabulka trvalých kotev úsek km 0,881 61 - km 1,005 14

Označení kotvy	délka kotvy (m)	délka kořene (m)	úhel (°)	počet pramenců	napínací síla (kN)
K38.1	10	3	12	2	100
K38.2	10	3	12	2	100
K38.3	13	3	12	2	180
K38.4	13	3	12	2	180
K39.1	10	3	12	2	100
K39.2	10	3	12	2	100
K39.3	13	3	12	2	180
K39.4	13	3	12	2	180
K40.1	10	3	12	2	100
K40.2	10	3	12	2	100
K40.3	13	3	12	2	180
K40.4	13	3	12	2	180
K41.1	10	3	12	2	100
K41.2	10	3	12	2	100
K41.3	13	3	12	2	180
K41.4	13	3	12	2	180
K42.1	10	3	12	2	100
K42.2	10	3	12	2	100
K42.3	13	3	12	2	180
K42.4	13	3	12	2	180
K43.1	10	3	12	2	100
K43.2	10	3	12	2	100
K43.3	13	3	12	2	180
K43.4	13	3	12	2	180
K44.1	10	3	12	2	100
K44.2	10	3	12	2	100
K44.3	13	3	12	2	180
K44.4	13	3	12	2	180
K45.1	10	3	12	2	100
K45.2	10	3	12	2	100
K45.3	13	3	12	2	180
K45.4	13	3	12	2	180
K46.1	10	3	12	2	100
K46.2	10	3	12	2	100
K46.3	13	3	12	2	180
K46.4	13	3	12	2	180
K47.1	10	3	12	2	100
K47.2	10	3	12	2	100
K47.3	13	3	12	2	180
K47.4	13	3	12	2	180
K48.1	10	3	12	2	100
K48.2	10	3	12	2	100
K48.3	13	3	12	2	180
K48.4	13	3	12	2	180
K49.1	10	3	12	2	100

Tabulka trvalých kotev úsek km 0,881 61 - km 1,005 14

Označení kotvy	délka kotvy (m)	délka kořene (m)	úhel (°)	počet pramenců	napínací síla (kN)
K49.2	10	3	12	2	100
K49.3	13	3	12	2	180
K49.4	13	3	12	2	180
K50.1	10	3	12	2	100
K50.2	10	3	12	2	100
K50.3	13	3	12	2	180
K50.4	13	3	12	2	180
K51.1	10	3	12	2	100
K51.2	10	3	12	2	100
K51.3	13	3	12	2	180
K51.4	13	3	12	2	180
K52.1	10	3	12	2	100
K52.2	10	3	12	2	100
K52.3	13	3	12	2	180
K52.4	13	3	12	2	180
K53.1	10	3	12	2	100
K53.2	10	3	12	2	100
K53.3	13	3	12	2	180
K53.4	13	3	12	2	180
K54.1	10	3	12	2	100
K54.2	10	3	12	2	100
K54.3	13	3	12	2	180
K54.4	13	3	12	2	180
K55.1	10	3	12	2	100
K55.2	10	3	12	2	100
K55.3	13	3	12	2	180
K55.4	13	3	12	2	180
K56.1	10	3	12	2	100
K56.2	10	3	12	2	100
K56.3	13	3	12	2	180
K56.4	13	3	12	2	180
K57.1	10	3	12	2	100
K57.2	10	3	12	2	100
K57.3	13	3	12	2	180
K57.4	13	3	12	2	180
K58.1	10	3	12	2	100
K58.2	10	3	12	2	100
K58.3	13	3	12	2	180
K58.4	13	3	12	2	180
K59.1	10	3	12	2	100
K59.2	10	3	12	2	100
K59.3	13	3	12	2	180
K59.4	13	3	12	2	180
K60.1	10	3	12	2	100
K60.2	10	3	12	2	100

Tabulka trvalých kotev úsek km 0,881 61 - km 1,005 14

Označení kotvy	délka kotvy (m)	délka kořene (m)	úhel (°)	počet pramenců	napínací síla (kN)
K60.3	13	3	12	2	180
K60.4	13	3	12	2	180
K61.1	10	3	12	2	100
K61.2	10	3	12	2	100
K61.3	13	3	12	2	180
K61.4	13	3	12	2	180
K62.1	10	3	12	2	100
K62.2	10	3	12	2	100
K62.3	13	3	12	2	180
K62.4	13	3	12	2	180
K63.1	10	3	12	2	100
K63.2	10	3	12	2	100
K63.3	13	3	12	2	180
K63.4	13	3	12	2	180
K64.1	10	3	12	2	100
K64.2	12	3	12	2	180
K64.3	13	3	12	2	180
K65.1	10	3	12	2	100
K65.2	12	3	12	2	180
K65.3	13	3	12	2	180
K66.1	10	3	12	2	100
K66.2	12	3	12	2	180
K66.3	13	3	12	2	180

Tabulka trvalých kotev úsek km 1,005 14 - km 1,221 21

Označení kotvy	délka kotvy (m)	délka kořene (m)	úhel (°)	počet pramenců	napínací síla (kN)
K67.1	10	3	11	2	100
K67.2	10	3	11	2	100
K67.3	13	3	11	2	180
K68.1	10	3	11	2	100
K68.2	10	3	11	2	100
K68.3	13	3	11	2	180
K69.1	10	3	11	2	100
K69.2	10	3	11	2	100
K69.3	13	3	11	2	180
K70.1	10	3	11	2	100
K70.2	10	3	11	2	100
K70.3	13	3	11	2	180
K71.1	10	3	11	2	100
K71.2	10	3	11	2	100
K71.3	13	3	11	2	180
K72.1	10	3	10	2	100
K72.2	10	3	10	2	100
K72.3	12	3	10	2	180
K73.1	10	3	10	2	100
K73.2	10	3	10	2	100
K73.3	12	3	10	2	180
K74.1	10	3	10	2	100
K74.2	10	3	10	2	100
K74.3	12	3	10	2	180
K75.1	10	3	10	2	100
K75.2	10	3	10	2	100
K75.3	1	3	10	2	180
K76.1	10	3	10	2	100
K76.2	10	3	10	2	100
K76.3	11	3	10	2	180
K77.1	10	3	10	2	100
K77.2	10	3	10	2	100
K77.3	11	3	10	2	180
K78.1	10	3	10	2	100
K78.2	10	3	10	2	100
K78.3	11	3	10	2	180
K79.1	9	3	11	2	100
K79.2	10	3	11	2	180
K80.1	9	3	11	2	100
K80.2	10	3	11	2	180
K81.1	9	3	11	2	100
K81.2	10	3	11	2	180
K82.1	9	3	11	2	100
K82.2	10	3	11	2	180
K83.1	8	3	10	2	100

Tabulka trvalých kotev úsek km 1,005 14 - km 1,221 21

Označení kotvy	délka kotvy (m)	délka kořene (m)	úhel (°)	počet pramenců	napínací síla (kN)
K83.2	10	3	10	2	180
K84.1	8	3	10	2	100
K84.2	10	3	10	2	180
K85.1	8	3	10	2	100
K85.2	10	3	10	2	180
K86.1	8	3	10	2	100
K86.2	10	3	10	2	180
K87.1	8	3	10	2	100
K87.2	10	3	10	2	180
K88.1	8	3	10	2	100
K88.2	10	3	10	2	180
K89.1	8	3	10	2	100
K89.2	10	3	10	2	180
K90.1	8	3	10	2	100
K90.2	10	3	10	2	180
K91.1	8	3	11	2	100
K91.2	9	3	11	2	180
K92.1	8	3	11	2	100
K92.2	9	3	11	2	180
K93.1	8	3	11	2	100
K93.2	9	3	11	2	180
K94.1	8	3	11	2	100
K94.2	9	3	11	2	180
K95.1	8	3	11	2	100
K95.2	9	3	11	2	180
K96.1	8	3	11	2	100
K96.2	9	3	11	2	180
K97.1	8	3	11	2	100
K97.2	9	3	11	2	180
K98.1	8	3	11	2	100
K98.2	9	3	11	2	180
K99.1	8	3	11	2	100
K99.2	9	3	11	2	180
K100.1	8	3	11	2	100
K100.2	9	3	11	2	180
K101.1	8	3	11	2	100
K101.2	9	3	11	2	180
K102.1	8	3	11	2	100
K102.2	9	3	11	2	180
K103.1	8	3	11	2	100
K103.2	9	3	11	2	180
K103.1	8	3	11	2	100
K103.2	9	3	11	2	180
K104.1	8	3	11	2	100
K104.2	9	3	11	2	180

Tabulka trvalých kotev úsek km 1,005 14 - km 1,221 21

Označení kotvy	délka kotvy (m)	délka kořene (m)	úhel (°)	počet pramenců	napínací síla (kN)
K105.1	8	3	11	2	100
K105.2	9	3	11	2	180
K106.1	8	3	11	2	100
K106.2	9	3	11	2	180
K107.1	8	3	11	2	100
K107.2	9	3	11	2	180
K108.1	8	3	11	2	100
K108.2	9	3	11	2	180
K109.1	8	3	11	2	100
K109.2	9	3	11	2	180
K110.1	8	3	11	2	100
K110.2	9	3	11	2	180
K111.1	8	3	11	2	100
K111.2	9	3	11	2	180
K112.1	8	3	11	2	100
K113.1	8	3	11	2	100
K114.1	8	3	11	2	100
K115.1	8	3	11	2	100
K116.1	8	3	11	2	100
K117.1	8	3	20	2	100
K118.1	8	3	20	2	100
K119.1	6	2	25	2	100
K120.1	6	2	25	2	100
K121.1	6	2	25	2	100